

Heron Weather Station Interface

1. Principal of Operation

The Heron Weather Station interface board allows one or more Heron Digital sensors to be connected to Mi or Ti irrigation controllers or to a Heron Environmental Controller. The following sensors can be connected to the Weather Station Interface board.

- Rain Sensor
- Light Sensor
- Humidity Sensor
- Temperature Sensor
- Wind Direction and Wind Speed sensor
- Raining Sensor

All sensors will be pre-wired except the wind sensor. Please refer to Appendix 1 which shows the connections for this.

3. Connecting to Controller

All weather station interface boards use a DIN connector. Wire the DIN connector as shown below. You can use the 24VAC power output that is available on your controller to power the interface.

